



Software rel. 1.0x

INSTALLATION, USE AND MAINTENANCE

02

LEGEND SYMBOLS

\ = Generic danger

/ = Warning

This manual is an integral part of the equipment to which it refers and must accompany the equipment in case of sale or change of ownership. Keep it for future reference; ARAG reserves the right to modify the specifications and instructions regarding the product at any time and without prior notice.

CONTENTS

•	Legend symbols2			
•	Forev	vord and guide to the manual	.5	
•	Using) the manual	.5	
•	Conv	entions	.5	
•	Liabil	ity	.5	
1	Risks	and precautions before assembly	.6	
2	Brave) DSB	.6	
3	Inten	ded use	.6	
4	Conte	ents of the package	.6	
5	Locat	tion on the machine	.7	
	5.1	Recommended system configuration	.7	
	5.2	Locating the computer	.8	
	5.3	Mounting the bracket	.8	
	5.4	Location of the control unit	.9	
6	Conn	ecting the computer to the machine	.9	
	6.1	General precautions for cable runs	.9	
_	6.2	Power connection	10	
7	Conn	ecting the cable to the control unit and services	11	
	7.1	Connecting the multi-pin connector	11	
	7.2	Connecting the valves	11	
_	7.3	Connecting the sensors and other services	12	
8	Acces	ssory connections	13	
	8.1	Pump Protector	13	
~	8.2	SD memory card	13	
9	Contr	Orstand display	14	
	9.1	Control panel	14	
	9.2	Punction keys	14	
	9.3	Control, selection and modification keys	14	
	9.4	Control unit valve switches.	14	
40	9.5	Display	14	
10	Menu	structure	15	
11	Adva	Dra anarramaning toota and chaole	10	
	11.1	Pre-programming tests and checks	10	
	11.2	Computer power-up / snutdown	16	
	11.3	How to view the menus.	10	
	11.4	Advanced menu	17	
	11.5	Language	18	
	11.0	Control measurement	10	
	11.7	Deem eature	18	
	11.0	Doom setup	19	
	11.9	Valves	2U ⊇4	
	11.10		≤ I 20	
	11.11		- <u>-</u>	
	11.12		-2	

CONTINUES

	11.13	Tank	23
	11.14	Filling flowmeter	23
	11.15	Rev. counter	24
	11.16	Foam Marker	24
	11.17	Pump Protector	25
	11.18	Configuration check upon completion of advanced setup	26
12	User	programming	27
	12.1	Speed	28
	12.1.1	Wheel constant: manual setting	28
	12.1.2	Wheel constant: automatic calculation	29
	12.2	Jobs setup	30
	12.3	Nozzles setup	32
	12.4	Working limits	33
	12.5	Flowrate correct. factor	33
	12.6	User preferences	34
	12.7	Date & Time	34
	12.8	Data logger	34
	12.9	Test	35
	12.10	Load/save setup	36
13	Funct	ion keys	37
	13.1	Job selection	37
	13.2	Job's data	37
	13.3	Zero transducer setup	38
	13.4	Tank	38
	13.5	Logger ON?	39
	106		
14	13.0	User setting	39
	Use	User setting	39 40
	Use 14.1	User setting Preliminary setup before application	39 40 40
	13.0 Use 14.1 14.2	User setting Preliminary setup before application Manual operation	39 40 40 41
	14.1 14.2 14.3	User setting Preliminary setup before application Manual operation Automatic operation	39 40 40 41 41
15	Use 14.1 14.2 14.3 Maint	User setting Preliminary setup before application Manual operation Automatic operation enance / diagnostics / repairs	39 40 40 41 41 41 42
15	Use 14.1 14.2 14.3 Maint 15.1	User setting	39 40 41 41 41 42 42
15	13.6 Use 14.1 14.2 14.3 Maint 15.1 15.2	User setting	39 40 41 41 41 42 42
15 16	13.6 Use 14.1 14.2 14.3 Maint 15.1 15.2 Techr	User setting	39 40 41 41 41 42 42 43 44
15 16	 Use 14.1 14.2 14.3 Maint 15.1 15.2 Techr 16.1 	User setting Preliminary setup before application Manual operation Automatic operation Errors during operation Troubleshooting ical data Data and units.	39 40 40 41 41 42 42 43 44 44
15 16	Use 14.1 14.2 14.3 Maint 15.1 15.2 Techr 16.1 16.2	User setting	39 40 40 41 41 42 42 43 44 44 46
15 16 17	Use 14.1 14.2 14.3 Maint 15.1 15.2 Techr 16.1 16.2 Dispo	User setting	 39 40 41 41 42 43 44 46 46 46

FOREWORD AND GUIDE TO THE MANUAL

This guide includes all instructions for correct assembly, connection and set up of BRAVO 300S computers.

Additional information specific to the different computer models is available on the data sheets for each models intended for use by installers only.

USING THE MANUAL

This manual contains information reserved for the installation technician, and hence makes use of technical terminology without the explanations which would otherwise be required by the end user.

THIS MANUAL IS FOR USE EXCLUSIVELY BY AUTHORIZED INSTALLATION TECHNICIANS.

THE MANUFACTURER IS NOT LIABLE FOR USE OF THIS MANUAL BY UNAUTHORIZED AND UNQUALIFIED PERSONS.

CONVENTIONS

The installation procedures described in this manual apply to all computer models, except where noted.

Model designations are mentioned where appropriate to identify special instructions for specific models.

LIABILITY

The installation technician is responsible for implementing the installation procedure in a professional manner so as to guarantee perfect functionality of the computer, whether supplied solely with ARAG components or with components from other manufacturers.

ARAG recommends using its own components for the installation of the control systems.

If the installation technician should decide to use components provided by other manufacturers, even if this should not require the modification of the cabling or other systems, he does so at his own exclusive risk and liability.

The installation technician is responsible for compatibility with components and accessories provided by other manufacturers.

If, as a consequence of the above recommendations, the computer or other ARAG components installed in combination with components provided by other manufacturers should suffer damage of any kind, no form of liability, whether direct or indirect, will be recognized by ARAG.

1 RISKS AND PRECAUTIONS BEFORE ASSEMBLY

All installation work must be done with the battery disconnected, using suitable tools and any individual protection equipment deemed necessary.



Use ONLY clean water for treatment tests and simulations: using chemicals during simulated treatment runs can seriously injure persons in the vicinity.

2 BRAVO DSB

ARAG has designed and manufactured a diagnostics system for Bravo series computers and the systems to which they may be connected.

BRAVO DSB (art. code 467003) provides reliable computer diagnostics (not of the control unit to which it is connected) so as to enable the resolution of any potential problems experienced with the system.

3 INTENDED USE

The device you have purchased is a computer which, when connected to a valve or suitable control unit, makes it possible to control all phases of treatment in agricultural applications directly from the cab of the agricultural machine in which it is installed.

CE This device is designed to work on agricultural machinery for crop spraying applications.

The machine is designed and built in compliance with EN ISO 14982 standard (Electromagnetic compatibility - Forestry and farming machines), harmonized with 2004/108/EC Directive.

4 CONTENTS OF THE PACKAGE

The following table lists the components contained in the BRAVO computers package:



5 LOCATION ON THE MACHINE

5.1 Recommended system configuration







Tab. 3

 $M_{\rm eff}$ The computer should be directly connected to the farm machine battery.

 $^{\prime\prime}$ * Do not connect the computer to a KEY ON power source (15/54).

5.2 Locating the computer

• BRAVO 30xS series computers must be installed in the cab of the tractor, in observance of the following precautions:



DO NOT install the computer in an area subject to excessive vibration or collisions as this may damage it or lead to its controls being accidentally actuated;
install the unit is a visible position within easy reach by hand: bear in mind that the computer should not obstruct the operator's freedom of movement or block his view.

M

Note the connections required for the computer to operate (table 4 and 5), the required length of the cables, and provide adequate space for the connectors and cable runs. An identification symbol is located next to each connector to indicate its function; for the configuration of the systems, refer to par. 5.1 - Recommended system configuration.



5.3 Mounting the bracket

The computer and control unit must be mounted on a bracket installed at the desired location (the previous paragraph shows the bracket drilling template).

The bracket must be extracted from its seat on the computer (A, Fig. 1) and installed using the provided bolts (B).

Make sure the bracket is securely mounted, fit the computer or control unit to it, and push it in until it locks in place (**C**).



5.4 Location of the control unit

The control unit must be installed with the special brackets supplied and mounted to the unit, positioning it as shown in the manual provided with it.



MAKE SURE TO FOLLOW ALL THE SAFETY INSTRUCTIONS GIVEN IN THE CONTROL UNIT'S MANUAL.

6 CONNECTING THE COMPUTER TO THE MACHINE

6.1 General precautions for cable runs

• Securing the cables:

- secure the cables so that they do not interfere with moving parts;

- route the cables in such a way that twisting and tractor movements cannot damage or break them.

• Routing the cables to protect against water infiltrations:

- branches in the cable runs must ALWAYS be oriented downwards (Fig. 2).



• Fitting the cables to the connection points.

- Do not force the connectors by pushing too hard or bending them: the contacts can be damaged and computer operation compromised.

• Use ONLY the cables and accessories listed in the catalogue; these have the correct specifications for their intended application.

6.2 Power connection

Inside the package (component 6 - Tab. 1) you will find the power connector required for the connection to the machine's battery; Fig. 6 shows the drilling template for installing the power connector. Connect the power connector to the battery poles using two 6 mm faston connectors, as shown in Figs. 4 and 5.

Use the cable provided in the package (component 7 - Tab. 1) to connect the computer to its power supply.





CAUTION!

Do not connect the power supply cables to the battery until you have completed the installation procedure; this will avoid possible short circuits.

Before powering up the computer and control unit, make sure the battery voltage is as specified (12 Vdc).

BRAVO 300S is powered directly from the battery (12 Vdc) of the agricultural machine it is installed on and must ALWAYS be switched on from the computer; when finished, switch the computer off manually using the suitable key on the control panel.

Keeping BRAVO 300S on for long periods of time when the machine is off may run down the tractor battery; be sure to switch off the computer if the machine is to be left unused with the engine off for some time.

Connect the power source as shown in Fig. 7.





CAUTION!

• The power circuit must ALWAYS be fitted with a 10 Amp automotive fuse.

• All battery connections must be made with cables with a minimum cross section of 2.5 mm².

To avoid short circuits, do not connect the power cable connector before the installation is completed.

• Use cables with suitable terminals to ensure correct connection of each individual wire.

7 CONNECTING THE CABLE TO THE CONTROL UNIT AND SERVICES

- Use only the cables provided with the ARAG computers.
- Take care not to break, pull, tear or cut the cables.
- Use of unsuitable cables or cables not provided by ARAG automatically voids the warranty.

• ARAG is not liable for damage to the equipment, persons or animals caused by failure to observe the above instructions.

7.1 Connecting the multi-pin connector

Connect the multi-pin connector to the panel and connect the other end of its cable to the control unit.

Make sure that it is correctly fitted and turn the collar clockwise until it locks in place.

7.2 Connecting the valves

• Use ARAG valves: in case of damages caused by the use of incorrect or non-Arag valves, warranty will be null and void.

• All valve connectors must be equipped with gaskets before installation (Fig. 8).

• Make sure the gaskets are correctly fitted to avoid infiltration of water when operating the control unit.

Fit the connectors to the valves following the markings given in the general system installation diagram in your possession (par. 5.1 - System recommended configuration).



• Remove the protector cap (1, Fig. 8) from the electrical valve.

• Fit the gasket (2) onto the connector (3) and push the connector fully on (4): take care not to bend the valve's electrical contacts.

• Tighten screw (5) fully down.



If there are more control panel switches than section valves, connect the wires as shown in Tab. 6.

NO. OF SECTION VALVES	SWITCHES TO BE USED	CABLES TO BE CONNECTED TO SECTION VALVES
2	2 - 4	2 - 4
3	2 - 3 - 4	2 - 3 - 4
4	1 - 2 - 4 - 5	1 - 2 - 4 - 5
6	1 - 2 - 3 - 4 - 5 - 6	1 - 2 - 3 - 4 - 5 - 6

Tab. 6

7.3 Connecting the sensors and other services

Fit the connectors to the services following the markings given in the general system installation diagram in your possession (par. 5.1 - System recommended configuration).

W Wiring cables are marked with symbols denoting their functions: please see Tab. 7 for correct wiring instructions.

ITEM MAIN CONNECTION		ALTERNATIVE CONNECTION
S	Speed sensor	
м	Pressure sensor	
F	Flow meter	
т	Filler flow meter	Pump Protector
R	Foam marker	
x	RPM sensor	Pump Protector
Р	Control valve	
G	Main valve	
1 ÷ 5	Section valves	

Tab. 7

Use ARAG sensors: use of unsuitable sensors or sensors not provided by ARAG automatically voids the warranty.

ARAG is not liable for damage to the equipment, persons or animals caused by failure to observe the above instructions.

- Instructions for sensor installation are supplied with the products.

The speed sensors listed below can also be used as RPM sensors:

- inductive speed sensor (code 467100.086).
- magnetic speed sensor (code 467100.100).
- Connection of:
- flowmeter
- pressure sensor
- Pump Protector
- filling flow-meter
- RPM sensor
- foam marker

All ARAG sensors use the same type of connector: plug the sensor connector into the matching wiring connector; make sure it is seated correctly and push until it locks into place.



8 ACCESSORY CONNECTIONS

8.1 Pump Protector

Optional sensor (**code 4664000.100**) is a device which, when connected to the computer, detects and signals breakage of the pump membrane or indicates when the oil level drops below its operational minimum level.

The preferred sensor input is always marked with an "X" on the cabling; if this input is not available, use the secondary input marked "T".

M CAUTION:

only use the secondary input "T" if the input marked "X" is occupied by another sensor.

Do not use the secondary input "T" if no sensor is connected to the "X" input, as the computer will not detect the Pump Protector in this configuration.

8.2 SD memory card

The SD memory card is used to exchange data with the BRAVO 300S computer.

 $\frac{1}{2}$ Ensure the card is not protected before starting to use it (Fig. 11).



 \wedge

ALWAYS power off the computer before inserting or removing the SD memory card.



Failure to insert the SD memory card in the computer will cause an error (par. 15.1).
 Store the SD memory card into the suitable case (supplied) when not in use.

9 CONTROLS AND DISPLAY

9.1 Control panel



Tab. 8

9.2 Function keys

	Job's data	
Sob selection	Logger ON?	
	Tank	
Lero transducer se	User setting	

9.3 Control, selection and modification keys



9.4 Control unit valve switches



9.5 Display



10 MENU STRUCTURE



11 ADVANCED SETUP

The computer can be programmed with the parameters required to ensure correct distribution of the treatment product.

This must be done once only, when installing the computer.

11.1 Pre-programming tests and checks



Before programming the computer check that:

- all components are correctly installed (control unit and sensors);
- the equipment is connected to its power sources;
- all components are correctly connected (control unit and sensors).

Incorrect connections of the components and the use of other components from those specified can damage the system or components themselves.

11.2 Computer power-up / shutdown

Normal power-up



Power-up for advanced setup



WARNING: ALWAYS power off the computer from the appropriate key, otherwise ALL treatment data will be LOST.

11.3 How to view the menus

When using BRAVO 300S, use the cursor > to select the appropriate menu: use the "arrow" keys (chap. 9 - Controls and display) to move the cursor to the desired option (Fig. 15). Now you may confirm your selection.





Ÿ

The minimum and maximum settable values for the parameters are given in paragraph 16.1 - Units of measurement.









section valves are operated independently.

Main switch control functions do not affect section valve opening or closing.

• "M" mode of operation:

section valve are closed or opened from the main switch provided that section valve switches are set in the appropriate position; in other words, if section switches are set to OFF (lever down), operating the main switch does not affect the sections. If one or more section valve switches are set to ON (lever up), opening or closing the main switch opens or closes the section valves as well.

Used to scroll data or edit values	Confirms access or change to data
L R Sets data to zero	Quits function or changes to data



Tab. 10

Used to scroll data or edit values	Confirms access or change to data
LR Sets data to zero	Uuits function or changes to data







11.14 Filling flowmeter

- Setting the type of filling flow-meter and its parameters Filling flowmeter > Type : Orion 462XXA4XXXX Minimum flowrate : 10,01/min							
> Selected set	Maximum flowrate : 200.0 1/min Selected setting Disabled Orion 462 Other						
	MEASUREMENT UNITS METRIC MEASUREMENT UNITS US						
TYPE	Constant (pls/l)	Min flowrate (I/min)	Max flowrate (I/min)	Constant (pls/l)	Min flowrate (I/min)	Max flowrate (I/min)	
462xxA4xxxx	300	10,0	200,0	1135	2,60	53,00	
4622xA5xxxx	150	20,0	400,0	568	5,00	106,00	
4622xA6xxxx	100	30,0	600,0	378	8,00	158,00	
Other	625	10,0	200,0	156	2,60	53,00	

Tab. 11









Used to scroll data or edit values	Confirms access or change to data
LR Sets data to zero	Uuits function or changes to data

This display screen appears upon exiting Advanced setup in the event any errors are found:





ロк



M

The minimum and maximum settable values for the parameters are given in paragraph 16.1 - Units of measurement.

	- Access speed calculation setup	
	S	peed
> Selected settin	>Source Selected wheel type Wheels setting	: Wheel sensor : 1 :
⊢ •	Wheel sensor	Select wheel type (3 types available)
	Pulses from speed sensor (mounted on wheel)	Select to access wheel constant edit mode: manual setting / automatic calculation
•	GPS data from GPS connected directly to auxili	ary port
2.1.1 Wheel cor	nstant: manual setting	
Constant fo	ormula:	
	distance travelled (cm)	
Kwheel = -	no. of measurement points x no. of wheel re	volutions
<distance distance in</distance 	travelled>	urement travel
<no. me<="" of="" td=""><td>easurement points></td><td></td></no.>	easurement points>	
number of	measurement points (e.g. magnets, bo	lts, etc.), mounted on wheel,
number of	wheel revolutions required to travel me	asurement distance.
	- Select a constant and access calculated va	alue setup
	Wheels	s setting
	Constant calculation	on : Manual · 55 24 cm/pls
	>Wheel constant 2	: 5.18 cm/pls
	Wheel constant 3	: 0.01 cm/pls
> Constant selec	cted for manual setting	

Take measurement with the tyres at operating pressure.

WHEEL CONSTANT: AUTOMATIC CALCULATION --->

Used to scroll data or edit values	Confirms access or change to data
L R Sets data to zero	Quits function or changes to data





Select the job you wish to set (there are 19 available); set the types to be used and disable the others. Current active job CANNOT BE EDITED

CONTINUES

Used to scroll data or edit values	Confirms access or change to data
LR Sets data to zero	Uuits function or changes to data











12.5 Flowrate correct. factor



- Access dispensed liquid density factor setup

Flowrate correct. factor

>1.00



When using a paddle wheel flowmeter, inaccurate readings may result if dispensed liquid does not have the same density as water; when this is the case, set the density factor of dispensed liquid so as to achieve correct calibration:

• decrease factor if there is fluid left in the tank after application is finished;

• increase factor if sprayer runs out of fluid before completing application.

ORION flow-meters (code 462xxx) are unaffected by liquid density: set factor to 1.00.

Used to scroll data or edit values	Confirms access or change to data
ELR Sets data to zero	Uuits function or changes to data



Used to scroll data or edit values DATE AND TIME: data scroll will not work	Confirms access or change to data
CLR Sets data to zero DATE AND TIME: scrolls data during editing	Quits function or changes to data





We recommend saving system setups to the SD memory card after you have completed installation and verified correct machine operation.

Download or save your settings to an SD memory card so you will be able to restore computer setup from the memory card, troubleshoot a problem or set up another BRAVO 300S.



CAUTION: WHEN YOU UPLOAD THE FILE setup.bin FROM THE SD MEMORY CARD TO BRAVO 300S, ALL CURRENT SETTINGS IN THE COMPUTER WILL BE LOST.

For detailed information on SD memory card data management, please read ADD_IN code D30037, available for download at www.aragnet.com

Used to scroll data or edit values	Ωκ Confirms access or change to data
L R Sets data to zero	Quits function or changes to data





		- Enable/disable application data logging		
	ĺ		Logger ON?	
			Logger OFF?	
		250 ^{+10%}		
			User setting	
	l			_
			User setting/	
				ar.
				2
13.6	User setti	ing		
		- Access user setup parameters		
	ſ		Logger ON?	
			User setting	
				וול
			Cap. 12 User setup	
			X- (O_	



14 USE

14.1 Preliminary setup before application

When	Setting	User setup	Function key	Par.
	Speed	•		12.1
	Job setup	•		12.2
	Nozzle setup	•		12.3
	Operating limits	•		12.4
FIRST START-UP	Rate correction factor	•		12.5
	User's preferences	•		12.6
	Date and time	•		12.7
	Data recorder	•		12.8
	Setup logging to SD memory card	•		12.10
	Type of wheel	•		12.1
	Rate correction factor	•		12.5
BEFORE EACH	Type of job		•	13.1
APPLICATION	Tank parameter		•	13.4
	Totalizer reset (at user's option)		٠	13.2
	Work data logging (at user's option)		•	13.5

Tab. 13



When finished with the above settings, choose MANUAL or AUTOMATIC operation and begin application.



14.3 Automatic operation



15 MAINTENANCE / DIAGNOSTICS / REPAIRS





Tab. 14

ור

	Alarm message	What do to	
Par. 9.4	Disable spraying command! Main switch ON upon computer power-up	Flip down main switch lever (set to OFF).	
Par. 14.3	Go! The machine is stopped ONLY for automatic operation: Main switch ON with machine stopped	Move off the machine.Flip down main switch lever (set to OFF).	
Par. 14.3	Start pump! No flowrate ONLY for automatic operation: Main switch ON, machine stopped, rate equals zero	Start the pump and move off the machine.	
Par. 12.3	Go slow! High pressure Pressure exceeds maximum level allowed for nozzle in use	 Slow down machine speed. Set operating pressure to within the limits set for the nozzles in use. Repeat the alarm setup procedure for nozzle minimum and maximum pressure alarms. 	
Par. 12.3	Go fast! Insufficient pressure Pressure below minimum level allowed for nozzle in use	 Increase machine speed. Set operating pressure to within the limits set for the nozzles in use. Repeat the alarm setup procedure for nozzle minimum and maximum pressure alarms. 	
Par. 12.2	Go slow! Insufficent flowrate Rate below minimum level required for application	Slow down machine speed.Verify correct setting of flow-meter constant.	
Par. 12.2	Go fast! High flowrate Rate exceeds level required for application	Increase machine speed.Verify correct setting of flow-meter constant.	
Par. 11.13	Reduce rotation speed! RPM exceeds maximum value allowed	Reduce RPM of moving part.	
Par. 11.13	Increase rotation speed! RPM below minimum value	Increase RPM of moving part.	
Par. 11.15	Stop immediately! Pump fault Pump oil level too low or water in oil	Stop the machine and check pump condition.	
Par. 11.8	Flowmeter out of range Rate outside limits allowed by flow-meter	 Set operating pressure to within the limits set for the nozzles in use. Verify correct setting of flow-meter constant. 	
Par. 8.2 - 12.10	SD card not found! Memory card was not inserted correctly	• Shut down computer and check that memory card is correctly seated in its slot.	
Par. 8.2 - 12.10	SD card write protected! Memory card is locked	Shut down computer and unlock memory card.	
Par. 12.10	SD card full! No space available on memory card	Make space for new data: delete any files you don't need from the memory card.	
Par. 12.10	SETUP.BIN: File not found! Computer setup was not saved	Save data.	
Par. 13.3	Signal out of range!Check transducer Abnormal pressure readings	• Verify pressure sensor condition and check for residual pressure in the system.	

- Clean only with a soft wet cloth.
- DO NOT use detergents or aggressive products.
 DO NOT aim water jets directly at the computer.

15.2 Troubleshooting

FAULT	CAUSE	REMEDY
Power supply missing		Check power supply cable connections.
Display will not turn on	Computer is OFF	Press the ON button.
Section valve controls take no effect	Valves not connected	Connect the connectors.
One valve will not open	No power supply to valve	Check wiring connection and valve operation.
Display doos not show spood	Wrong setup	• Check wheel constant setting (par. 12.1).
Display does not show speed	No signal from speed sensor	 Check connections to speed sensor.
Speed readout inaccurate	Wrong setup	• Check wheel constant setting (par. 12.1).
Volume sprayed readout inaccurate	Wrong setup	 Check boom width setting (par. 11.8). Check flow-meter constant setting (par. 11.10). Check wheel constant setting (par. 12.1). Check section valve type setting (par. 11.9). Check connections to speed sensor.
		• Check boom width setting (par. 11.8).
Covered area count displayed does not match actual covered area	Wrong setup	Check wheel constant setting (par. 12.1). Check connections to speed sensor.
	Covered area count not reset	Reset counter.
Distance travelled count displayed does not match actual distance	Wrong setup	 Check wheel constant setting (par. 12.1). Check connections to speed sensor.
covered	Distance travelled count not reset	Reset counter.
Dispensed fluid count displayed	Wrong setup	 Check flow-meter constant setting (par. 11.10). Check section valve type setting (par. 11.9).
does not match litres/gpm actually	Distance travelled count not reset	Reset counter.
uispenseu	Three-way section valves in use, but no backflow calibration	Perform calibration.
Time count displayed does not match actual time worked	Work time count not reset	Reset counter.
	Wrong setup	 Check application rate setting (par. 12.2). Check boom width setting (par. 11.8).
Spray volume set for automatic operation cannot be achieved	System not adequately sized to provide required rate	 Check maximum pressure valve setting. Make sure control valve is adequate for specific system.
	Control valve malfunction	Check valve operation.
	Wrong setup	Check pressure sensor full scale setting.
Instantaneous pressure readout	Pressure sensor not calibrated	Perform calibration (par. 13.3).
inaccurate	Pressure sensor improperly installed	Check connections to pressure sensor.
	Wrong setup	Check pressure sensor setting (par. 11.11).
Instantaneous pressure not	Computer receives no signals from speed sensor	Check connections to pressure sensor.
aispiayea	Pressure sensor improperly installed	Check connections to pressure sensor.
RPM readout inaccurate	Wrong setup	• Check RPM sensor constant setting (par. 11.15).
RPM not displayed	Computer receives no signals from RPM sensor	Check connections to RPM sensor.
	RPM sensor improperly installed	Check connections to RPM sensor.
Pump failure alarm permanently active	Computer receives no signals from Pump Protector sensor	Check connections to Pump Protector sensor.
Tab. 15		

16.1 Data and units

Advanced menu

Datum	Description	Min.	Max.	UM	Notes
Language	Display language				Languages available: Italian, English, Spanish, Portuguese, French, German,
					Czech, Polish, Russian
Unit of	Measurement				Possible settings:
measurement	unit displayed				Metric, US
Section	Number of section				Possible settings:
valvos numbor	valves installed in				1 · 7
valves number	the system				1 - 7
Boom cotup	Width of each	0.0	00.00 -	Metric: m	_ Data item is displayed when width
boom setup	boom section	0,0	33,33	US: ft	of each boom section is set
					Possible settings:
	Boom section				2-way - no calibrated backflow
					3-way - calibrated backflow
					Possible settings:
	Automatic shutoff				No (P mode)
					Yes (M mode)
Valves					Possible settings:
	Pressure control				2-way
					3-way
					Possible settings:
					2-way
	Main				3-way
					Nono
					Possible sottings:
	Type of flow-meter	<u> </u>			Possible Settings.
				Motrio: I/min	Minimum rate for correct flow motor
	Min rate alarm	Disabled	999,9		
Flowmeter				US: gai/min	Operation Maximum rate for correct flow mater
	Max rate alarm	Disabled	999,9		Maximum rate for correct now-meter
				US: gai/min	operation
	Flow-meter constant	1	32000	Metric: pis/i	Data required for rate calculation
				US: pis/gai	Describle a stimula
Duese	Туре				Possible settings:
Pressure			50.0		Disabled, 466112.200, 466112.500, Other.
sensor	Max pressure		50,0	Metric: bar	_Data required to determine instantaneous
<u> </u>		1	2200	US: psi	pressure
Delivery cal.	Sensor used				Possible settings:
sensor	to calculate output				Flowmeter, Pressure, Either
	Tank capacity	1	10000	Metric: I	
Tank			1000	US: gal	
	Tank reserve value		1998	Metric: I	Below this value, the computer triggers
		0	528	US: gal	an alarm message with a warning sound
Filling	Type				Possible settings:
flowmeter	.);;;;				Disabled, Orion 462xxAxxxxx, Other
	Rev counter constant	Disabled	999	Metric - US: pls/turn	
				Metric - US:	Below this value, the computer
Rev counter	Minimum speed alarm	No	10000	nls/turn	triggers an alarm
				Metric - LIS:	Above this value, the computer
	Maximum speed alarm	No	10000	nls/turn	triggers an alarm
				piortuiti	Possible settings:
Foam marker	Foam marker operation				Automatic Semi-autom Manual
	Pump diaphragm				Possible settings
Pump Protector	failure alarm				Enabled Disabled
	ianaro aiaritt				

Tab. 16

User programming

Datum	Description	Min.	Max.	UM	Notes
	Sourco				Possible settings:
					Wheel sensor, GPS
	Selected wheel type				Up to three wheel types can be stored
	Wheels setting				Includes the following submenus:
Sneed					Constant calculation, Wheel constant
opood	Constant calculation				Possible setting: Manual, Automatic
	Wheel constant	0.01	150	Metric: cm/pls	Number of constant to be set:
			1000	US: inches/pls	1÷3
	Reference distance		1000	Metric: m	_Distance to be travelled during automatic
	A 11 11 1 1 1 1 1	60	3000	US: teet	constant calculation
	Available job selection				Possible setting: 01 ÷ 14
Jobs setup	Application rate	Disabled	9999	US: gpa	Supports "Varying application rate"
	Nozzle				Possible settings:
	NOZZIC				ISO 01 ÷ 20, Type A ÷ E
	Flowrate	0.01	99 99	Metric: I/min	
	Tiomato	0,01	00,00	US: gpm	Value can ONLY be edited for
	Pressure	0,1	99,9	Metric: bar	custom-made nozzles
Nozzles setup				US: psi	
	Minimum	Disabled	99 9	Metric: bar	
	pressure alarm		,-	US: psi	_Value can be edited for
	Maximum	Disabled	99.9	Metric: bar	custom-made and ISO nozzles
	pressure alarm			US: psi	
	Nozzle wear monitoring	Disabled	50	Metric / US:	
				%	
	Min spraying speed	Disabled	999.9	Metric: km/n	
				US: mpn	Includes the following entires:
Working limits					Includes the following optionsi:
	Regulation lockout type				Disabled, Min. regulation speed,
				N	Min. regulation pressure
	Min regulation speed	0,1	99,99	Metric: km/n	
				US: mpn	
	Min regulation pressure	0,1	99,9	Metric: bar	
Flowroto	<u> </u>			US: psi	
		0,1	10,0		
correct. factor					

Tab. 17

CONTINUES

• Delivery values

Datum	Description	Min.	Max.	UM
	Quantity of fluid dispensed per unit	0	9999	Metric: I/ha
Applied quantity	of surface area	0	999	US: gpa
Cread	Vehiele aneed	0	00	Metric: km/h
Speed	venicie speed	0	99	US: mph
Elourata	Quantity of fluid dispensed per unit of time	0	999,9	Metric: I/min
FIOWIALE				US: gpm
Drocouro	Coroving processo	0	999,9	Metric: bar
Pressure	Spraying pressure	0	9999	US: psi
Tank loval	Fluid lovel left in tank	0	0000	Metric: I
Tarik level	Fluid level leit in tank	0	9999	US: gal
Rev counter	RPM	0	9999	Metric / US: RPM

Tab. 18

Counters

Datum	Description	Min.	Max.	UM
Covered area	Area append	0.000	00000	Metric: ha
Covereu area	Area covered	0,000	99999	US: acres
Applied questity	Dispensed fluid	0	99999	Metric: I
Applied quantity		0		US: gal
Timo	Time worked	00:00	00000	Metric: h
Time	Time worked	00.00	99999	US: h
Distance traveled	Distance to will ad	0.000	00000	Metric: km
Distance traveled	Distance travelled	0,000	99999	US: miles
Tab 10				

Tab. 19

16.2 Computer technical data

Description	BRAVO 30XS
Display	White backlit 240 x 73 graphic LCD
Power supply	11 ÷ 14 Vdc
Consumption (only computer)	450 mA
Working temperature	0 °C ÷ 60 °C +32 °F ÷ +140 °F
Digital inputs	for open collector sensors: max. 2000 imp./s
Analog inputs	4 ÷ 20 mA
Weight	1015 g (Bravo cod. 46730501 without wiring)
Protection against reversal of polarity	
Protection against short circuit	•

Tab. 20

17 DISPOSAL AT THE END OF SERVICE

Dispose of the system in compliance with the established legislation in the country of use.



18 GUARANTEE TERMS

 ARAG s.r.l. guarantees this apparatus for a period of 360 day (1 year) from the date of sale to the client user (date of the goods delivery note). The components of the apparatus, that in the unappealable opinion of ARAG are faulty due to an original defect in the material or production process, will be repaired or replaced free of charge at the nearest Assistance Centre operating at the moment the request for intervention is made. The following costs are excluded:

- disassembly and reassembly of the apparatus from the original system;

- transport of the apparatus to the Assistance Centre.
- 2. The following are not covered by the guarantee:
 - damage caused by transport (scratches, dints and similar);

- damage due to incorrect installation or to faults originating from insufficient or inadequate characteristics of the electrical system, or to alterations resulting from environmental, climatic or other conditions;

- damage due to the use of unsuitable chemical products, for spraying, watering, weedkilling or any other crop treatment, that may damage the apparatus;

- malfunctioning caused by negligence, mishandling, lack of know how, repairs or modifications carried out by unauthorised personnel;

- incorrect installation and regulation;

- damage or malfunction caused by the lack of ordinary maintenance, such as cleaning of filters, nozzles, etc.;

- anything that can be considered to be normal wear and tear.
- 3. Repairing the apparatus will be carried out within time limits compatible with the organisational needs of the Assistance Centre.

No guarantee conditions will be recognised for those units or components that have not been previously washed and cleaned to remove residue of the products used.

- 4. Repairs carried out under guarantee are guaranteed for one year (360 days) from the replacement or repair date.
- 5. ARAG will not recognise any further expressed or intended guarantees, apart from those listed here.

No representative or retailer is authorised to take on any other responsibility relative to ARAG products.

The period of the guarantees recognised by law, including the commercial guarantees and allowances for special purposes are limited, in length of time, to the validities given here. In no case will ARAG recognise loss of profits, either direct, indirect, special or subsequent to any damage.

- 6. The parts replaced under guarantee remain the property of ARAG.
- 7. All safety information present in the sales documents regarding limits in use, performance and product characteristics must be transferred to the end user as a responsibility of the purchaser.
- 8. Any controversy must be presented to the Reggio Emilia Law Court.

Conformity Declaration CE

ARAG[®]

ARAG s.r.l. Via Palladio, 5/A 42048 Rubiera (RE) - Italy P.IVA 01801480359

Dichiara

che il prodotto descrizione: Computer modello: Bravo 300S e Bravo 300S Selejet serie: 46730xxx, 46731xxx, 46734xxx e 46736xxx

risponde ai requisiti di conformità contemplati nelle seguente Direttiva Europea: 2004/108/CE e successive modificazioni (Compatibilità Elettromagnetica)

Riferimenti alle Norme Applicate:

EN ISO 14982:2001

(Macchine agricole e forestali - Compatibilità elettromagnetica Metodi di prova e criteri di accettazione)

Rubiera, 23 Aprile 2009

Giovanni Montorsi

(Presidente)





Only use original ARAG accessories and spare parts, to maintain safety conditions foreseen by the constructor. Always refer to the ARAG spare parts catalogue.

10/2009

D20154_GB-m03



42048 RUBIERA (Reggio Emilia) - ITALY Via Palladio, 5/A

Tel. 0522 622011 Fax 0522 628944

http://www.aragnet.com info@aragnet.com